SUPPER
FOOD AS A SERVICE

SOP MICROWAVE PROGRAMMING

Dear SUPPER-chef,
This SOP will help you update your SUPPER microwave.

Step 1: Open the microwave settings

1. Open the door.
2. Press and hold number 2 on the microwave for 5 seconds until you see: OP: --
3. Press number 8 > now you see OP: 80.
   NOTE: Do you see OP:81? > Press START, close the door and go to STEP 2!
4. Press number 8 again > now you see OP: 81.
5. Press START to confirm > now you see OP: --
6. Close the door.

Step 2: Enter a new program

1. Open the door.
2. Press and hold number 1 on the microwave for 5 seconds until you see: PROGRAM.
3. Enter the program number (e.g., 40) > Now you see 0:00 and %Power in the lower right corner.
4. NOTE: For each program, you can set 3 stages; for some programs (e.g., 41), only stage 1 is programmed. In this case, proceed directly to step 9.

Example:

nr.	stage 1		stage 2		stage 3		
	time	power	time	power	time	power	total
40	01:30	30	00:20	100	01:50	40	03:40
41	03:30	50					03:30

Explanation based on program 40:

5. Start with stage 1, enter time (e.g., 1:30) > press power level, enter number (e.g., 3).
6. Press 'time entry' > now you are in stage 2.
7. Enter time (e.g., 20) > press power level.

NOTE: If nothing is indicated for 'power level,' the microwave operates at 100% power.

8. Press 'time entry' > now you are in stage 3.
9. Enter time (e.g., 1:50) > press power level, enter (e.g., 4).
10. Press Start.
11. Close the door.

REPEAT steps 1 to 9 for all subsequent programs (e.g., 41, 42).

Step 3: Close the microwave settings

1. Open the door.
2. Press and hold number 2 for 5 seconds until you see: OP: --
3. Press number 8 > now you see OP: 81.
4. Press number 8 again > now you see OP: 80.
5. Close the door.