SUPPER
FOOD AS A SERVICE

UPLOAD PROGRAMS

Uploading programming to the microwave via USB port (Maestrowave)

1. **Activate**
   Activate the microwave by opening and closing the door; it is now in standby mode.

2. **Insert USB stick**
   Insert the USB stick into the right side of the control panel of the microwave. Note: the contacts of the stick should be on the left.

   BEEP! Confirmation of connection.

3. **Upload menu**
   a. Open the door (from standby mode) and keep it open.| The display shows **"0",**

   b. Press and hold the PROG button for 3 seconds until… | Display **“PROG”**

   c. Hold button number 4 to start the upload process. |Display **“00FL”** -> **“99FL”**
   BEEP! Confirmation that the download is complete. |Display **“FHFL”** and **“PROG”**

   d. Press stop until the display returns to 0.

4. **Remove USB stick**
   Remove the USB stick.

   Your menu has now been successfully uploaded to the microwave and is ready for work!